# Qoreline

## **2PC Thread Ends Ball Valve**



### Usage

Maximum lifetime of the valve can be maintained under normal conditions and in accordance with pressure temperature rating and corrosion data.

#### **Operation instructions**

□ The opening and closing of the valve is done by turning the handle a quarter turn (90° turn).

The valve handle is marked showing proper rotation direction for "ON" and "OFF" positions. Rotation is clockwise for "OFF" (closed) and counterclockwise for "ON" (open).



Valve in OPEN position: The handle is in line with the valve or pipeline. Valve in CLOSED position: The handle is across the pipeline.

#### Installation instructions

- □ Make sure the spacing between the pipe endings corrospond to the face-to-face dimensions of the ball valve. The pipeline should be supported.
- □ The pipeline should be checked for proper alignment before installation.
- □ The pipes must be purged before installation.
- □ Sealant is applied to the pipe thread (Packing yarn, Teflon tape, Locktite etc.).
- □ The ball valve is recommend to be installed with stem towards up on pipeline, since the deposited dirt may damage the seal if turned downward.
- By assembling or disassembling of the valve, only use tool on the 6-sides thread end of the valve with adjustable wrench.



#### Ball valve function test

□ Gradually open and close the valve until a full 90° turn is obtained. In this way you make sure that the seat is shaped against the ball. This is particularly important when installing new seats.

#### Storage instructions

- $\hfill\square$  It is recommend to keep the original packing material during storage.
- □ Store the valve in a clean, dry, consistent temperature environment to protect it against dirts and damp.
- $\hfill\square$  It is recommend that the valve keep in fully open postion in storge period.
- □ Keep the plastic covers on both ends of ball valve to prevent any dirts from getting inside ball cavity during storge.

Wuxi Coreline Valve Co., Ltd.	Phone:	+86 510 68870699
210 Xinyuan Rd, Ehu Industrial Park, Xishan	Fax:	+86 510 80257773
Wuxi,214116	Email:	mail@coreline-valve.cn
China	Web:	www.coreline.dk